

K171 FITTING INSTRUCTIONS

These fitting instructions contain information specific for your vehicle. They should be read in conjunction with your crossbar instructions.

Kit Contains

1 x Set of assembly Instructions
4 x Clamps

Items you may require that are not included:

1 x Tape measure

Instructions

Replace the Standard Rubber Pads that come with the Crossbar with the Stepped Pads supplied in this fitting kit. Clamps directly to edge of roof under the doors.

Maximum
P-Bar
Load
Rating

40
kg

When Fitted and loaded
correctly

Crossbar Spacing

