

K190 FITTING INSTRUCTIONS

These fitting instructions contain information specific for your vehicle. They should be read in conjunction with your crossbar instructions.

Kit Contains

- 1 x Set of assembly instructions
- 4 x Clamps
- 4 x Rubber Pads

Items you may require that are not included:

- 1 x Tape measure

Instructions

Clamps directly to edge of roof under the doors

Crossbar Spacing

Maximum
P-Bar
Load
Rating

50
kg

When Fitted and loaded
correctly

